

Payment on the BENY terminal

Before you start

- 1 Park and switch the vehicle off.
- 2 Cable and plug must be undamaged and dry.
- 3 If the screen is red or shows a **fault** , do not charge — call staff.

Pay with a bank card (POS)

- 1 Take gun A or B. If both guns are in use, follow **user A** / **user B** on the screen.
- 2 Plug the CCS connector into the car. The green lamp may flash.
- 3 On the LCD choose a method: **card** **MAC** **QR code** **POS machine**
- 4 For a bank card, tap **POS machine** .
- 5 For QR payment tap **QR code** — the ePunjači app is required (see section below).
- 6 Follow the POS terminal next to the screen (tap/insert card, PIN if asked).
- 7 Wait until charging starts (**charging is starting**). The screen shows voltage, current, energy and time.
- 8 Do not unplug while the inlet green lamp is on. The **running water** lamp is on while energy flows.

Stop charging

- 1 Tap **STOP** (lower right).
- 2 If prompted, present the card on the reader until the beep (settlement).
- 3 Return the gun to the holster.

Pay with QR code — the ePunjači app is required

Required: ePunjači app

QR payment works only with the ePunjači app. Install it, create an account and sign in BEFORE you scan. Without the app you cannot pay via QR code on the charger.

- 1 Install the ePunjači app (App Store or Google Play) and sign in.
- 2 On the charger LCD tap **QR code** .

- 3 In the ePunjači app open the scanner and scan the QR code on the charger screen.
- 4 Confirm the gun and payment in the app. Charging starts after successful authorization.

Other options on the same screen

card

RFID charging card — hold it on the reader until the beep.

QR code

The ePunjači app is REQUIRED. Sign in, tap QR code on the charger, then scan the code in the app. QR payment is not possible without ePunjači.

MAC

MAC / app payment, if configured.

POS machine

Bank card on the charger's attached POS terminal.

Emergency

Press the red emergency stop (mushroom). Power cuts immediately. When it is safe, ROTATE the button to reset; charging will not restart until you do. This is payment on the BENY pile (factory POS / card / QR / MAC).

